



RYOBI

Cordless Telescopic Patio Floor Cleaner, 18V, With Scrubbing Brush, 3.9kg

Brand: Ryobi
SKU: RY18PCB-120
Warranty: 24

- Upright hands-free cleaning without kneeling or bending
- Powered brush removes moss and grime with minimal effort
- Quick-change brush system saves time during cleaning
- Comfortable ergonomic design for extended use
- Cordless freedom using Ryobi ONE+™ batteries

Specifications

Battery pack capacity (Ah)	2
Power	18V
Battery type	Li-ion
Charging time (min)	75
Sound power level (Lwa) (dB(A))	80
Sound pressure level (Lpa) (dB(A))	66.5
Vibration level (m	s ²) / 0.8
Weight (without battery) (kg)	3.5
Weight with battery pack (EPTA) (kg)	3.9
No. of batteries supplied	1
Charger included	RC18120
Weight	3.9 KG
Weight	3.9 KG